



Application Type	ROUNDS			OVALS		
	Küp Small	Küp Large	Küp Extra Large	Kanü Small	Kanü Large	Kanü Extra Large
Aaton 16	•					
Aaton 35	•					
Alphatron						•
Arri 235		•				
Arri 2B	•					
Arri 2C	•					
Arri 435		•				
Arri 535		•				
Arri Alexa		•				
Arri Alexa LF		•				
Arri Alexa M		•				
Arri Alexa Mini		•				
Arri Alexa Mini		•				
Arri Alexa Plus		•				
Arri Alexa Plus 4:3		•				
Arri Alexa XT M		•				
Arri Alexa XT Plus		•				
Arri Alexa XT Studio		•				
Arri Amira		•				
Arri cameras but looser than Küp Large				•		
Arri SR2		•				
Arri SR3		•				
Blackmagic eyecup		•				
Bolex H16		•				
Canon C100, C200, C300 using Miller C-Cup		•				
Canon C100, C200, C300, C500						•
Canon C700					•	
Canon GL2	•					
Canon XF100	•					
Canon XF300, XF305, XF205 HD						•
Canon XL H1					•	
Canon XL1 & XL2					•	
Deity Mira loupe						•
Hitachi videocam		•				
Hoodman Loupe Hoodloupe 3.0	•					
JVC GY100U					•	
JVC GY-HD100U		•				
Kamerar LCD Viewfinders QV series						•
Kinor 16 SX-2M	•					
Letus Hawk				•		
Magview series						•
Miller & Schneider for Lumix GH4 & GH5	•					
Moviecam	•					
Panasonic AG-HVX20	•					
Panasonic AG-HVX20					•	
Panasonic AK-UC3000					•	
Panasonic Cameras with round eyecup	•					
Panasonic DVCPRO HD					•	
Panasonic GH3/GH4, G Cup version		•				
Panasonic HC-X1000					•	
Panasonic HDX 900P					•	

Application Type	ROUNDS			OVALS		
	Küp Small	Küp Large	Küp Extra Large	Kanü Small	Kanü Large	Kanü Extra Large
Panasonic HMC41 & HMC81					•	
Panasonic Varicam 27F HD					•	
Panasonic Varicam 4K					•	
Panavision Genesis with auto iris	•					
Panavision Millenium	•					
RED Digital Cinema, most models						
Small HD 502 sidefinder		•				
Sony 900 & 900S					•	
Sony A7 Series with A-Cup		•				
Sony Betacam				•		
Sony BVW 300					•	
Sony CBK-VF01					•	
Sony DCR-SD1000					•	
Sony EX1 & EX3					•	
Sony F3			•			
Sony F5					•	
Sony F55 4K					•	
Sony F800					•	
Sony FS-100					•	
Sony FS5						•
Sony FS7				•		
Sony HD					•	
Sony HD with large padded cup			•			
Sony HDRFX 1000	•					
Sony HDWF900R					•	
Sony HVR-HD1000					•	
Sony HVR-S270						•
Sony HXR-MC1500 & MC2000					•	
Sony HXR-NX100						•
Sony HXR-NX70					•	
Sony NEX FS-700					•	
Sony NEX-FS100E					•	
Sony PDW F335					•	
Sony PDW-700 and similar					•	
Sony PMW series				•		
Sony PVW500					•	
Sony PXW series				•		
Sony PXW-X320, X400					•	
Sony PXW-Z150						•
Sony Venice					•	
Viper HD					•	